


Topic 18-A. Resetting Prognostics


18-A.1 Resetting Prognostics V. 1.14/1.17

Figure 18-3: Resetting Prognostics



188

Figure 18-4: Resetting Prognostics (continued)




189

Figure 18-5: Resetting Prognostics (continued)



190

Figure 18-6: Resetting Prognostics (continued)



191

Use the arrow down button on either the touch screen or soft touch button to select the item to be reset.


Figure 18-7: Password Entry



192

To reset the service item, push the Reset button and the soft button at the same time.

Figure 18-8: Two Button Salute




193

You will only have to enter the password for the reset of the first service item, then you can reset each with the "two button salute."

The 7 digit password is the truck number, unit number

Figure 18-9: Resetting



194

Once the password is entered, the rest of the prognostics can be reset without re-entering the password.


18-A.2 Resetting Prognostics V. 2.04/2.13

Figure 18-10: Resetting Prognostics



195

Figure 18-11: Login




196

18-A.2.1 Prognostics Reset V. 2.04

Figure 18-12: Prognostics Reset

Prognostics Reset
V. 2.04

- Log into the truck as the administrator or maintainer
 - Password will be Truck and unit number starting with a "T"
 - Proceed to the prognostics screen through the start menu
 - Scroll to the item you want to reset and press reset and center button simultaneously to reset back to maximum value
 - To use a laptop or tablet you must login as Administrator/ Maintainer and generate a mobile code
- If you do not have a display you can not reset prognostics.




197

Figure 18-13: Menu Button




198

Figure 18-14: Select Setup



199

Figure 18-15: Select Password



200


Figure 18-16: Password Entry



201

If password is incorrect login button will light green but display will not move on from password screen. When the correct password is entered the screen will automatically move on.

Figure 18-17: Select Prognostics



202

Select Prognostics.


Figure 18-18: Menu Button



203

Press the menu button.

Figure 18-19: Select Prognostics



204

Select Prognostics.

Figure 18-20: Arrow Down



205

Use the arrow down button on either the touch screen or soft touch button to select the item to be reset.

Figure 18-21: Two Button Salute



206


To reset the service item, push the Reset button and the soft touch button at the same time.

18-A.2.2 Creating a Mobile Code

Figure 18-22: Mobile Code

Creating a Mobile Code

- Logging into the truck with a WIFI device, a 2.04/2.13 truck will not show the technician badge and password
- Instead a Mobile code must be generated.
- To generate,
 - Login as administrator or maintainer on the display
 - Then under passwords select mobile
 - Follow the instructions and generate a mobile code.
 - Enter mobile code on device
 - Ensure the park brake is set, and you hold the service brake until code is entered
 - Until login is complete prognostics will be greyed out




207

18-A.2.3 Prognostics Reset V. 2.13

Figure 18-23: Prognostics Reset

Prognostics Reset
V. 2.13

- Follows the same process as 2.04
- Uses a linked reset feature
 - Prognostics with the same interval settings are reset at the same time



208

Topic 18-B. Navigating the Setup Menu

Figure 18-24: Navigating Setup Menu

WE'LL ALWAYS BE THERE
Pierce
PIERCE SERVICE
Module 18
Topic B: Navigating the Setup Menu



209

Figure 18-25: Select Setup



Select Setup.

210